



5 x 3V Battery CR2032



10 x Necklace-Set



flathead screwdriver


Accessories Zubehör



1 x Magnet for reset

Battery change Batterie wechseln

Only by authorized personnel!
Nur durch Fachpersonal!



Cleaning the transmitter and the accessories Reinigung Sender und Zubehör



Not to be used: alcohol, alcohol or vinegar-based cleaning agents, vinegar, cleaning agents for glass or plastics, disinfectants (except Incidur®), methylated spirits, benzine, other aggressive agents, body lotion, sun cream, hand and nail cream. Do not wash.

Nicht benutzen: Alkohol, Reinigungsmittel mit Alkohol oder Essig, Essig, Reinigungsmittel für Glas oder Kunststoffe, Desinfektionsmittel außer Incidur®, Brennspiritus, Waschbenzin, andere aggressive Mittel, oder Body Lotion, Sonnenmilch, Hand- und Nagelcreme. Nicht waschen.

D Bosch Sicherheitssysteme GmbH
Haus-ServiceRuf
Ingersheimer Straße 16
D-70499 Stuttgart
Deutschland
Tel: +49 (0)711 3653 1000
Fax: +49 (0)711 811 5125 294

F Bosch Security Systems France
Atlantic 361
361, avenue du Général de Gaulle
F-92147 Clamart
France
Tel: + 33 (0)825 12 8000 (0,15 € TTC/Min)
Fax: + 33 (0)820 900 960 (0,12 € TTC/Min)

G Bosch Security Systems Ltd
Broadwater Park
North Orbital Road
Denham
UB9 5HN
United Kingdom
Phone: +44 (0)1895-878088
Fax: +44 (0)1895-878089

CH TeleAlarm SA Bosch Group
Rue du Pont 23
CH-2300 La Chaux-de-Fonds
Switzerland
Phone: +41 (0)32 327 25 40
Fax: +41 (0)32 327 25 41


B Bosch Security Systems nv/sa
Torkonijestraat 21F
B-8510 Marke
België / Belgique
Tel: +32 (0)56 20 02 40
Fax: +32 (0)56 20 26 75

NL Bosch Security Systems BV
Postbus 80002
NL-5600 JB Eindhoven
Nederland
Tel: +31 40 25 77 200
Fax: +31 40 25 77 202

SE Bosch Security Systems AB
Vestagatan 2
SE-416 64 Göteborg
Sverige
Telefon: +46 (0)31 722 5300
Fax: +46 (0)31 722 5340

S35 & S35Q Pendant Transmitters Funksender

Operating instructions Bedienungsanleitung



CRS-SB-023FI
CRS-SB-033FI
CRS-SB-037FI
CRS-SC-424FM
S35 Pendant Transmitter 434 with necklace
S35 Pendant Transmitter 434 without necklace
S35Q Pendant Transmitter 434 with reset possibility
S35 Pendant Transmitter 869




970.050 V1 2009.06

BOSCH

Trigger an emergency call

Notruf auslösen



Safety notes

Sicherheitshinweise



Repairs only by authorized service stations

Reparaturen nur durch autorisierte Servicestellen


Shortening the cord

Kordel kürzen



Changing the wearing method

Tragenarten wechseln



Technical data

Technische Daten

	H x W x D : 75 mm x 40 mm x 25 mm 40 g
	1 x CR2032 3V
	0°C ~ +55°C
	Frequency S35 434 : 434.01 MHz Frequency S35 869: 869.2125 MHz
	Minimum range in free field: 200 m
	Automatic radio link monitoring: daily check and at every alarm

