

**New behavior concerns the following transmitters with order numbers:**

- S35 Pendant Transmitter with reset possibility (RP) F.01U.140.047
- S37 Wristband Transmitter RP F.01U.140.052
- S37 Wristband Transmitter with red button and RP F.01U.140.056
- S37L Wristband Transmitter with Locating function F.01U.140.053

**For all transmitters listed above:**

- the LED is now yellow:



- new mode change:

-> 3 x acknowledgements, then 1 x press button

- by default, no automatic alarm repetition

**Additionally, for S37L Wristband Transmitter F.01U.140.053:**

- it now offers an alarm button

- alarms can be triggered max. 5 seconds after acknowledgement

- transmitter programming is simplified