

CareSoft APP Training

Paul Leferink






1. Install the APP on your Android smart phone: careSOFT_ada.apk

Probably such a message will appear:

For security, your phone is set to block installation of apps obtained from unknown sources.

CANCEL SETTINGS

Press "SETTINGS" and go to "Unknown sources"



Press "OK" and then "Install"




2. Run the EXE file "PDAServer.exe" on your CareSOFT PC with Dongle:

The presence of the license file "For example: 1616309022.exe "will be checked automatically

The file name is the License No. of the Dongle


3. Such an EXE file will be sent only to TeleAlarm after ordering the careSOFT APK APP license



Remark: The delivered license will be equipped with only the ordered amount of apps



4. Copy folder: 12-PDAServer_V2.xx to 0-careSOFT



5. (This will be on the standard TeleAlarm CareSOFT CD later)




4



6. CareSOFT- Systems: Create a new System PDA Server





7. (will be standard in caresoft.con data base)




6



CareSoft APP

8. New System PDA Server: Create new Unit Types



9. Nummer



10. (will be standard in caresoft.con data base)





11. Setting files:

Name A	Size	Туре	Date Modified	
PDAServer.exe	124 KB	Application	27.05.2013 08:34	
PDAServer.lng	1 KB	LNG File	12.08.2013 15:42	
PDAServer.locations	1 KB	LOCATIONS File	13.08.2013 10:49	
PDAServer.paging	4 KB	PAGING File	27.05.2013 08:34	
PDAServer.settings	1 KB	SETTINGS File	27.05.2013 08:34	
PDAServer_Version.txt	1 KB	Text Document	27.05.2013 08:34	


PDAServer.settings - General settings: Ports, etc.

PDAServer.paging - How the alarm types are displayed on the smart pone

PDAServer.lng - Language specific version can be created


PDAServer.locations - Locating of the smart phone via MAC-Address of the Access Point







13. Start PDAServer.exe Connection to CareSOFT How many PDAs are connected with the PDA Server






















Settings



PDA No. like in CareSOFT programmed, e.g. 123




IP Address of the CareSOFT PC






Settings



IP Port: 16001 like in PDAServer.settings




WLAN: 5 Sec 5 Min only for technical Alarms outside WLAN






offline



online





© TeleAlarm Group





Any other questions?

Thank you for your attention

